

Product manual

Learning: Press the learning key, it means the controller putting in the learning state when the indicator goes ON, then please press any buttons of the remote control to transmit signals, the indicator will flash for 3 times after 1 second, then recover to normally OFF, which means successfully studied.

After pressing any buttons of the remote control to transmit signal, the indicator didn't flash, 10 seconds later it still recovers to normally on, but it study unsuccessfully.

Cleaning: Hold press learning button about 8 seconds, indicator from ON to OFF, then press remote receiver did not work, it means cleaning code successful.

A: Signal non-lock (jog): press the NO.1 button of the remote control to learn

B: Signal self-lock (self-lock): press the No.2 button to learn, each channel is independent of the others

C: Signal inter-lock: press the NO.3 button to learn

D: 1CH-3CH is jog, 4CH-6CH is self-lock press the NO.4 button to learn

E: 1CH-3CH is jog, 4CH-6CH is inter-lock press the NO.5 button to learn

F: 1CH-2CH is jog, 3CH-6CH is inter-lock press the NO.6 button to learn

